



www.WamplerPedals.com

Underdog Overdrive Manual

Thank you for purchasing the Wampler Pedals' Underdog Overdrive Pedal. This short guide will explain how the pedal works and how to get the optimum sound with the pedal through your equipment.

There are five knobs on this pedal controlling volume, gain, treble, mids, and bass. The toggle adds some midrange thickness.

Start out with the eq (treble, mids, and bass) at 12:00 and add more bass if you need it. Then, tailor the treble for the brightness you need. Finally, tweak the mids to allow a warmer tone, or a more 'scooped' type of tone. Adjust gain and volume to taste.

There is a battery connection inside, if you would like to use it you will need to open the bottom plate and insert a battery.

If using a power supply, power needed for the pedal is a regulated 9vdc center pin negative, just like most standard Boss™/Ibanez™/Etc type pedals.

Warranties

There is a 7-day "no questions asked" period where you may return the pedal if you do not like the sound of it. You will need to pay for shipping to us, however, and if anything is damaged or broken (except for malfunction or premature wear) we will have to deduct that from the refund. The 7 days start upon receipt of pedal. This is not valid if purchasing through a dealer however. In this instance, ask your dealer where you purchased for their warranty should you wish to return the pedal.

The warranty period on this pedal is 5 years parts and labor unless due to abuse. For warranty repairs on these pedals, please contact us first by going here:

<http://www.wamplerpedals.com/contact>

Enjoy!